



No.	Part name	Qty
A-1	Limiting Stopper	1
A-2	Foam Pipe	1
A-3	Flat Washer	4
A-4	Knob	4
A-5	Bolt	4
A-6	Handle Plug	2
A-7	Bolt	2
A-8	Nut	2
A-9	Rope Guide	1
A-10	Nut	1
A-11	Cable Support	2
A-12	Cable Fixing Clamp	1
A-13	Brake Cable	1
A-14	Upper Handle	1
A-15	Lower Handle	1
A-16	Brake Lever	1
A-17	Clutch cabel	1
A-18	Clutch Lever	1
B-1	Upper Cover of Left Panel	1
B-2	Lower Cover of Left Panel	1
B-3	Handle	2
B-4	Cable	1
B-5	Bolt	2
B-6	Screw	2
B-7	Spring	2
B-8	Nut	6
B-9	Bolt	2
B-10	Bolt	2
B-11	Upper Cover of Right Panel	1
B-12	Lower Cover of Right Panel	1
B-13	Cable	1
B-14	Bush	1
B-15	Screw	4
B-16	Screw	6
B-17	Handle Panel	1
C-1	Engine	1
C-2	Bolt	3
C-3	Flat Key	1
C-4	Blade adapter	1
C-5	Blade Washer	1
C-6	Blade Bolt	1
C-7	Screw Cap	2
C-8	Screw	4
C-9	Belt Cover Plate	1
C-10	Belt Cover Plate	1
C-11	Belt Cover	1

C-12	20" Blade	1
C-13	Engine cover	1
C-14	Screw	2
C-15	Filtering Net Duct of Fuel	1
C-16	Oil Pipe Circlip I	1
D-1	Height Adjustment Plate	1
D-2	Bolt	4
D-3	Nut	4
D-4	Right Bracket	1
D-5	Left Bracket	1
D-6	Deck	1
D-7	Mulching Plug	1
D-8	Cable Sleeve	1
D-9	Washing Linker	1
D-10	Screw	1
D-11	plug	2
D-12	Rear Cover Spring	1
D-13	Rear Cover Shaft	1
D-14	Rear Cover Support	2
D-15	Bolt	3
D-16	Nut	3
D-17	Rear Cover Pedestal	1
D-18	Rear Cover	1
D-19	Screw	2
D-20	Guard?board	1
D-21	Nut	3
D-22	Fixed plate	1
D-23	Bolt	3
D-24	Nut	2
D-25	Bolt	2
D-26	Side Discharge Cover Spring	1
D-27	Screw	2
D-28	Cover Plate	1
D-29	Spring	1
D-30	Lock	1
D-31	Side Discharge cover	1
D-32	Side-Discharge Guiding Board	1
D-33	Side Discharge Cover Shaft	1
D-34	Side Discharge Bracket	1
E-1	Height Adjustment Handle	1
E-2	Spring Washer	2
E-3	Nut	2
E-4	Bolt	4
E-5	Nut	4
E-6	Height adjustment Spring	1
E-7	Nut	1
E-8	Split Pin	1

E-9	Connecting Rod	1
E-10	Shaft Sleeve	2
E-11	Spring	1
E-12	Lock Ring	4
E-13	Pin	2
E-14	Left Gear	1
E-15	Right Gear	1
E-16	Flat Washer	2
E-17	Bolt	2
E-18	Nut	2
E-19	Bush	4
E-20	Flat Washer	8
E-21	plate	3
E-22	plate	1
E-23	Bush	4
E-24	Bolt	4
E-25	Nut	4
E-26	Rear Wheel Shaft	1
E-27	11" wheel	2
E-28	11" Outer Wheel Cover	2
E-29	Bolt	2
E-30	Inner Wheel Cover	2
E-31	Connecting rod	1
E-32	8" Wheel	2
E-33	8" Outer Wheel Cover	2
E-34	Wheel axle	2
E-35	Spring Washer	2
E-36	Pin	2
E-37	rotating shaft	2
E-38	Lock Ring	2
E-39	Lock Knob	2
E-40	Screw	4
E-41	upper cover of Lock	2
E-42	Spring	2
E-43	Pin	2
E-44	lower cover of Lock	2
E-45	Holder	1
E-46	holder	1
E-47	Screw	4
E-48	upper cover	1
E-49	Lower cover	1
E-50	Belt	1
E-51	Gearbox	1
E-52	Flat Washer	2
F-1	Metal Bracket	1
F-2	Flat Washer	2
F-3	Screw	4

F-4	fixed plate	2
F-5	Plastic Cover	1
F-6	Cover Plate	1
F-7	Handle cover	1
F-8	Indicated Board	1
F-9	Fabric bag	1