





No.	Part name	QTY
		
1	Hexagon bolt	1
2	Cylinder head cover	1
3	Cylinder head cover gasket	1
4	Air valve adjustment bolt	2
5	Air valve rocker arm (gasoline)	2
6	Intake valve spring seat	2
7	Air valve spring	2
8	Oil Seal	2
9	Intake valve	1
10	Exhaust valve	1
11	Limit plate	1
12	Bolt	4
13	Cylinder head	1
14	Hexagon flange locking nut	2
15	Muffler cover	1
16	Muffler	1
17	Exhaust valve gasket	1
18	Stud bolt	2
19	Spark plug	1




20	Stud bolt	2
21	Intake gasket	1
22	Heat insulation plate	1
23	Carburetor gasket	1
24	Carburetor	1
25	Air cleaner gasket	1
26	Primer intake pipe	1
27	Air cleaner	1
28	Hexagon flange nut	3
29	Exhaust air pipe	1
30	Cylinder head gasket	1
31	Locating pin	2
32	Push rod	2
33	Tappet	2



34	Piston assy	1
35	Piston pin retainer	2
36	Piston	1
37	Pinston pin	1
38	Connecting rod assy	1
39	cross recessed tapping screw	5
40	Big cover decoration for starter	
41	Big cover for starter	1
42	Smalll cover for starter	1
43	Fuel tank filter	1
44	Fuel pipe	1
45	Spring clamp	2
46	Fuel tank	1
47	Fuel tank cap	1



48	Hexagon flange nut	1
49	Starting cup	1
50	Impellar	1
51	Fly wheel	1
52	Oil seal	1
53	Stud bolt	1
54	Hexagon flange bolt	8
55	Ignitor	1
56	Crankcase	1
57	Switch wire	1
58	Breathing valve assy	1
59	Cross recessed screw	1
60	Fuel return chamber cover gasket	1
61	Fuel return chamber cover	1
62	Hexagon flange bolt	2
63	Hexagon flange bolt	2
64	Brake assy	1
65	Brake spring	1



66	Throttle assy	1
67	Governing spring A	1
68	Throttle lever	1
69	Governing arm	1
70	Oil seal	1
71	Washer	1
72	Cotter pin	1
73	Governing spring B	1
74	Governor holder	1
75	Oil ruler	1
76	Locating pin	2
77	Camshaft	1
78	Crankshaft	1
79	Crankshaft timing gear	1
80	Crankshaft flat washer	1
81	Governing gear assy	1
82	Crankcase cover	1
83	Oil seal	1