






Crankcase cover

No.	Part No.	Description	Quantity
1	5787.08035.00.01	Blot	7
2	F80.1230.001.00.01	Oil gauge ass.	1
3	F80.1010.001.00.00	Crankcase cover	1
4	5789.06010.00.01	Blot	1
5	173.0270.005V.00.00	Ball bearing	1
6	148.1020.001.00.00	Warning device	1
7	5787.06014.00.01	Blot	2
8	168.3170.001.00.00	Set pin	2
9	F80.3040.001.00.00	Gasket, Crankcase	1
10	F80.1040.001.60.00	Camshaft ass.	1




Crankcase

No.	Part No.	Description	Quantity
1	180. 0210. X01. 00. 00	Piston ring ass.	1
2	F80. 0200. 001. 00. 00	Piston	1
3	168. 0230. 001. 00. 00	Clip, Piston pin	2
4	F80. 0220. 001. 00. 00	Piston pin	1
5	F80. 0190. 001. 00. 00	Connecting rod assembly	1
6	5787. 06025. 00. 01	Blot	2
7	F80. 2100. 001. 00. 00	High pressure bag	1
8	F80. 1000. 001. 00. 00	Crankcase body	1
9	F80. 0180. 001. 00. 00	Crankshaft ass.	1
10	173. 3150. 001. 00. 00	Oil seal	1
11	168. 1260. 001. 66. 00	Gasket for oil drain bolt	2
12	168. 1250. 001V. 00. 20	Oil drain bolt	2
13	168. 3170. 001. 00. 00	Set pin	2
14	F80. 1521. 001. 00. 00	Trigger	1
15	F80. 2090. 001. 00. 00	Crimping board	1
16	5787. 06014. 00. 01	Blot	1
17	5789. 06028. 00. 01	Blot	2
18	5789. 05016. 00. 07	Blot	2
19	F80. 2070. A01. 00. 00	Starting motor	1




Motor assembly

No.	Part No.	Description	Quantity
1	528.4000.002.00.00	Motor stator	1
2	5787.06065.00.01	Blot	3
3	528.4000.001.00.00	Motor rotor	1
4	F80.2030.001.00.00	Flywheel fan	1
5	F80.2020.002.00.00	Starting sleeve	1
6	6177.14000.06.01	Nut	1
7	5787.06014.00.01	Blot	4




Cylinder head parts

No.	Part No.	Description	Quantity
1	5787.06025.00.01	Blot	4
2	F80.0001.001.00.01	Cylinder head cover	1
3	F80.2370.001.00.00	Exhaust pipe	1
4	F80.7061.001.00.00	Breathing valve plate assembly	1
5	F80.7061.002.00.00	Breathing valve pad	1
6	5789.05010.00.07	Blot	1
7	F80.3000.001.00.00	Cylinder head cover pad	1
8	F80.6985.001.00.00	Cylinder head cover	1
9	5787.10075.05.10	Blot	4
10	168.2160.008.00.00	Spark plug	1
11	0900.06102.00.01	Blot	2
12	0900.08032.00.01	Blot	2
13	F80.0010.001.00.00	Cylinder head	1
14	188.3170.002.00.00	Set pin	2
15	F80.3020.001.00.00	Gasket, Cylinder head	1




Engine Starter

No.	Part No.	Description	Quantity
1	F80.2000.002.00.01	Starting hood	1
2	5787.06018.00.01	Blot	5
3	148.2000.001.00.01	Starting handle	1
4	T48.2186.001.00.01	Handle cover	1
5	T70.2000.0020.00.01	Pull the plate	1
6	5787.06014.00.01	Blot	4




Air distribution

No.	Part No.	Description	Quantity
1	5787.06014.00.01	Blot	1
2	165.0085.001.00.00	Oil seal, Intake valve	1
3	F70.0107.020.00.00	Rocker shaft stop	1
4	F80.0100.001.00.00	Rocker ass.	2
5	K92.0105.001.00.01	Rocker shaft	2
6	168.0090.001V.00.00	Valve top cap	2
7	165.1120.001.00.00	Valve collet	2
8	165.0060.001.00.00	Valve spring seat	2
9	F80.0040.001.00.00	Valve spring	2
10	F80.0030.001.00.00	Exhaust valve	1
11	F80.0020.001.00.00	Intake valve	1
12	F80.0160.001.00.00	Pusher	2
13	F68.1030.001.00.00	Tappet	2




Carburetor parts

No.	Part No.	Description	Quantity
1	F80. 2260. 001. 00. 00	Carburetor ass.	1
2	F80. 3060. 001. 00. 00	Gasket, inlet port	1
3	F80. 2300. 001. 00. 00	Carburetor block	1
4	F80. 3080. 001. 00. 00	Gasket, carburetor	1




Air cleaner

No.	Part No.	Description	Quantity
1	F80. 2280. 0010. 00. 00	Air cleaner ass.	1
2	168. 3095. 008. 00. 00	Air filter paper pad	1
3	6177. 06000. 00. 01	Nut	2




Inverter

No.	Part No.	Description	Quantity
1	526. 6452. 0010. 00. 00	Rubber connecting sleeve	1
2	526. 4623. 0010. 00. 00	Inverter inner cover	1
3	528. 2470. 001V. 00. 00	Inverter	1
4	526. 8452. 0010. 00. 00	Inverter bracket1	1
5	526. 8452. 0020. 00. 00	Inverter bracket2	1
6	6177. 06000. 00. 01	Locking nut with disc	2
7	526. 4624. 0010. 00. 00	Inverter cover	1
8	5787. 06016. 00. 01	Bolt	7
9	526. 9844. 0010. 00. 00	DC control module	1




Muffler parts

No.	Part No.	Description	Quantity
1	526.2400.0010.00.00	Muffler components	1
2	526.2440.0010.00.00	Muffler bracket	1
3	T70.3100.001V.00.00	Exhaust port gasket	1
4	6170.08000.00.01	Hexagon nut	2
5	5787.08016.00.01	Bolt	4




Frame

No.	Part No.	Description	Quantity
1	526.3331.0010.D7.00	Frame components	1
2	526.7390.0010.00.00	Front wheel	2
3	526.3335.0010.04.00	Wheel axle	2
4	526.5010.0010.00.00	Handle plug	2
5	5787.08045.00.01	Bolt	2
6	6177.08000.00.01	Locking nut with disc	10
7	526.3339.0010.D7.00	Handle assembly	2
8	526.7136.0010.00.00	Handle rubber sleeve	2
9	6177.06000.00.01	Locking nut with disc	6
10	5787.06040.00.01	Bolt	4
11	526.4437.0010.00.00	Shock mount bracket	2
12	460.3360.002V.00.00	Shock pad	2
13	5787.06025.00.01	Bolt	2
14	526.3340.0020.00.00	Dynamic fixed base plate 2	1
15	526.3340.0010.00.00	Dynamic fixed base plate 1	1
16	528.3360.002V.00.00	Shock pad 2	4
17	526.7341.0010.21.00	R-type bolt	2



Panel

No.	Part No.	Description	Quantity
1	526.3370.0010.00.01	Panel rear cover	1
2	526.3370.0010.00.00	Control panel combination	1
3	5787.06012.00.01	Bolt	4
4	5787.05012.00.01	Bolt	9



Fuel tank components

No.	Part No.	Description	Quantity
1	526. 3200. 0010. D7. 00	Tank	1
2	460. 3203. 001V. 00. 00	Fuel tank cap	1
3	460. 3204. 001V. 00. 00	Fuel filter screen	1
4	460. 3207. 001V. 00. 00	Indicator as-oil level	1
5	460. 3210. D01V. 00. 00	Fuel tank switch	1
6	460. 3213. 001V. 00. 00	Tank bushing	4
7	460. 3217. 001V. 00. 00	Oil tank mounting rubber sleeve	4
8	460. 4100. 001V. 20. 00	Non standard flat pad	4
9	5787. 06025. 00. 01	Bolt	4