



NO.	Part name	quantity
1	THE CRANKSHAFT BOX BODY	1
2	SWINGING ROD	1
3	PENDULUM STEM SEAL	1
4	IGNITER	1
5	THE FLYWHEEL COMPONENTS	1
6	FAN,RECOIL STARTER	1
7	PULLEY,STARTER	1
8	EXHAUST PIPE	1
9	CYLINDER CRANIUM	1
10	PLATE,BREATHER	1
11	BOLT M4*6	1
12	CRANKCASE COVER	1
13	CARBURETOR CONNECTION BLOCK	1
14	CARBURETOR ASSEMBLY	1
15	BACK TO THE OIL CHAMBER	1
16	THE PISTON	1
17	PISTON RING ASSEMBLY	1
18	THE PISTON PIN	1
19	PISTON PIN RETAINER	2
20	THE SPARK PLUG	1
21	OIL GAUGE ASSEMBLY	1
22	EXTENSION, OIL FILLER	1
23	INLET VALVE	1
24	VALVE OIL SEAL	2
25	INLET VALVE SPRING SEAT	2
26	AIR FILTER ELEMENT	1
27	CENTRIFUGAL GOVERNOR GEAR ASSEMBLY	1
28	CONNECTING ROD COMPONENT	1
29	NUT M12*1.25	1
30	BOLT M6X16	8
31	BOLT M6X25	7
32	BOLT M8X45	4
33	STUD M6X92	2
34	AIR FILTER GASKET	1
35	INTAKE GASKET	1
36	CARBURETOR GASKET	1
37	THE EXHAUST VALVE	1
38	VALVE SPRINGS	2
39	THE VALVE LIFTER	2
40	THE VALVE PUSH ROD	2
41	THE CRANKSHAFT	1
42	FLAT WASHER	1
43	POSITIONING PIN OF CRANKCASE	2
44	GASKET,BREATHER	1
45	CYLINDER HEAD	1
46	THE CRANKSHAFT OIL SEAL	1
47	THE CRANKSHAFT OIL SEAL	1
48	CRANKSHAFT TIMING DRIVING GEAR	1
49	FUEL PIPE	1
50	IN THE HOOD	1
51	SPEED REGULATING SPRING B	1
52	CONTROL ARM	1
53	MUFFLER HOUSING	1
54	FILTER	1
55	FLAMEOUT WIRE	1
56	SPEED CONTROL CONTROLLER	1
57	CAMSHAFT ASSEMBLY	1
58	MUFFLER	1
59	ROCKER ARM	2
60	THE THROTTLE LEVER	1
61	THE FUEL TANK	1
62	THE CAP	1
63	CHECK BACK CLIP	1
64	PIN, ARM, ROCKER	1
65	WIND SHIELD,RH	1
66	WIND SHIELD,RH	1
68	HOOD,FAN	1
69	BOLT M4.2*16	3
70	PACKING,EXHAUST	1
71	BOLT M6*10	4
72	FLAT WASHER	1
73	NUT M6	2
74	NUT M6	2
75	STUD	2
76	FUEL PIPE CLAMP	2
77	THE BRAKE COMPONENTS	1
78	BRAKE SPRING	1
79	BOLT M6*22	1
80	BOLT M6*30	2
81	TUBE	1
82	BOLT M6*12	2
83	FLAT KEY	1