



No.	Part name	Qty.
1	Switch box assembly	1
1-1	Switch box upper cover	1
1-2	Switch button	1
1-3	Switch spring	1
1-4	Switch	1
1-5	Switch bracket	1
1-6	Switch Torsional spring	1
1-7	Line-hanging device	1
1-8	Self-attack screw	2
1-9	Fixed plate	1
1-10	Push rod	1
1-11	Connecting Rod	1
1-12	Handle protective sleeve	1
1-13	Torsional spring	1
1-14	Self-attack screw	2
1-15	Bracket	1
1-16	Self-attack screw	1
1-17	Auxiliary handle left cover	1
1-18	Auxiliary bushing	2
1-19	Auxiliary handle right cover	1
1-20	Self-attack screw	9
1-21	Switch box lower cover	1
1-22	Plug	1
1-23	Power source protective sleeve	1
1-24	Cable line	1
1-25	Connecting line	2
1-26	Switch bushing	2
1-27	Cable Pressplate	1
2	Pin	4
3	Quick clip handle	4
4	Quick clip gasket	4
5	Bolt	2
6	Lower handle	1
7	Thread buckle	1
8	Grass box assembly	1
8-1	Grass collecting bag	1
8-2	Indicator panel	1
8-3	Grass box upper cover	1
8-4	Grass box handle	1
8-5	Grass collecting box bracket	1
9	Adjusting tooth	2
10	Rear wheel assembly	1
10-1	Rear right wheel cover	1
10-2	Retaining Ring	2
10-3	Rear wheel	2
10-4	Washer	2

10-5	Rear wheel shaft assembly	1
10-6	Left rear wheel cover	1
11	Upper cover assembly	1
11-1	Back cover assembly	1
11-2	Adjusting gear cover	1
11-3	Nut	2
11-4	Rear cover shaft	1
11-5	Screw	2
11-6	Shaft retaining ring	2
11-7	Rear cover Torsional spring	1
11-8	Upper cover handle	1
11-9	Dust gasket	2
11-10	Self-attack screw	6
11-11	Motor cover	1
11-12	Gear plate	1
11-13	Gear soft plate	1
11-14	Upper cover	1
12	Wheel shaft positioning plate	2
13	Self-attack screw	13
14	Screw	2
15	Motor assembly	1
15-1	Motor	1
15-1-1	Screw	2
15-1-2	Spring washer	2
15-1-3	Self-attack screw	4
15-1-4	Carbon brush	2
15-1-5	Flat Washer	2
15-1-6	Motor rear bracket	1
15-1-7	Washer	1
15-1-8	628 Bearing	1
15-1-9	Rotor assembly	1
15-1-10	Bearing	1
15-1-11	Stator assembly	1
15-1-12	Motor end cover	1
15-1-13	Nut	7
15-1-14	Fan blade	1
15-1-15	Small Belt pulley	1
15-2	Heat shrink tube	0.05
15-3	Male terminal	1
15-4	Electromagnetic assembly	1
15-5	Elastic retaining ring for shaft	1
15-6	Bearing	1
15-7	Motor bracket	1
15-8	Self-attack screw	7
15-9	Spring Pressplate	3
15-10	Brake skin	1
15-11	Self-attack screw	6

15-12	Brake pad	3
15-13	Speed regulation spring	3
15-14	Big Belt pulley	1
15-15	Bearing 6002-2RS	1
15-16	Brake disc	1
15-17	6003 Bearing	1
15-18	Polywedge band	1
15-19	Motor bracket	1
15-20	Cable tie	2
16	Machine casing assembly	1
16-1	Right fixed tooth	1
16-2	Washer	4
16-3	Bottom disc	1
16-4	Self-attack screw	12
16-5	Left fixed tooth	1
16-6	Out grass guide plate	1
16-7	Self-attack screw	2
16-8	Left side carding grass block	1
16-9	Front bottom disc	1
16-10	Right side carding grass block	1
17	Gasket	1
18	Height adjusting spring	1
19	Height-adjusting assembly	1
19-1	Height adjusting lever	1
19-2	Adjustable connecting rod	1
19-4	Torsional spring	1
19-3	Pin	1
20	Screw	1
21	Height adjusting handle	1
22	Nut	2
23	Screw	2
24	Output shaft sleeve	1
25	Blade locating plate	1
26	Blade	1
27	Blade Pressplate	1
28	Blade bolt	1
29	Front wheel assembly	1
29-1	Front right wheel cover	1
29-2	Retaining Ring	2
29-3	Front wheel	2
29-4	Washer	2
29-5	Front wheel shaft assembly	1
29-6	Front left wheel cover	1
30	Gasket	3
31	Self-attack screw	1
32	Self-attack screw	6