



A-1 CRANKCASE ASSY




No.	Part name	Qty	No.	Part name	Qty
1	crank-case	1	8	BOLT FLANGE	2
2	cable clamp	1	9	BOLT FLANGE	1
3	SHAFT GOVERNOR ARM	1	10	cable clamp	1
4	shim,SHAFT GOVERNOR ARM	1	11	crankshaft seal	1
5	Clip,SHAFT GOVERNOR ARM	1	12	bearing	1
6	NUT	1	13	WASHER DRAIN PLUG	2
7	oil alert	1	14	BOLT DRAIN PLUG	2

A-2 CYLINDER HEAD & CYLINDER HEAD COVER ASSY




No.	Part name	Qty	No.	Part name	Qty
15	Cylinder head bolt	1	20	Diverion hood	1
16	BOLT FLANGE	4	21	BOLT FLANGE	1
17	Exhaust pipe Paper pad	1	22	cylinder gasket	1
18	Location Pin	2	23	cylinder head	1
19	spark plug	1	24	cylinder head cover	1

A-3 CRANKCASE COVER ASSY




No.	Part name	Qty	No.	Part name	Qty
25	bearing	1	31	bearing	1
26	BOLT FLANGE	7	32	speed regulating gear	1
27	crank-case cover	1	33	Speed regulating gear gasket	1
28	Location Pin	2	34	Oil plug assembly	1
29	Crankcase gasket	1	35	Oil Ruler Assembly	1
30	crankshaft seal	1	I		1

A-4 CRANKSHAFT, PISTON, CONNECTING & BALANCING SHAFT




No.	Part name	Qty	No.	Part name	Qty
36	connecting rod bolt	2	44	Oil ring scraper ring	1
37	connecting rod	1	45	piston ring A	1
38	connecting rod cover	1	46	piston ring B	1
39	piston pin	1	47	Balance axis	1
40	Piston pin Retaining ring	2	48	crankshaft	1
41	piston	1	II	connecting rod Assy.	1
42	Oil ring scraper ring	1	III	Piston Ring	1
43	Oil ring lining ring	1			

A-5 Combination of camshaft & Valve rocker




No.	Part name	Qty	No.	Part name	Qty
49	camshaft	1	58	LEFTER VALVE	2
50	VALVE EX	1	59	LEFTER VALVE	2
51	VALVE IN	1	60	PLATE ASSY	1
52	Exhaust valve spring	1	61	Stud bolt,rocker arm	2
53	Exhaust valve spring seat	1	62	ARM VALVE ROCKER	2
54	Inlet valve spring seat	1	63	Rocker arm adjusting nut	2
55	Valve top cap	1	64	Rocker Hexagon Head Nut	2
56	Inlet valve spring seat	1	IV	rocker arm Assy	1
57	Oil shield	1			

A-6 CARBURETOR ASSY




No.	Part name	Qty	No.	Part name	Qty
65	INSULATOR CARBURETOR	1	67	CARBURETOR	1
66	PACKING CABURETOR	1	68	SPACER COMP AIR CLEANER	1

A-7 FUEL TANK ASSY




No.	Part name	Qty	No.	Part name	Qty
69	Oil pipe clamp	1	74	FILTER FUEL	1
70	cable clamp	2	75	Hexagonal flange bolt	2
71	TUBE FUEL	1	76	NUT	2
72	fuel tank	1	V	FUEL tank	1
73	fuel tank cap	1			

A-8 AIR CLEANER ASSY




No.	Part name	Qty	No.	Part name	Qty
77	filter element	1	82	TUBE BREATHER	1
78	COVER AIR CLEANER	1	83	ELBOW COMP AIR CLEANER	1
79	gasket	1	84	NOSE SILENCER	1
80	NUT	2	85	filter element	2
81	NUT	1	VI	air-filter	1

A-9 MUFFLER




No.	Part name	Qty	No.	Part name	Qty
86	NUT	2	88	Exhaust pipe Paper pad	1
87	shock pad	2	89	MUFFLER ASSY	1

A-10 RECOIL STARTER




No.	Part name	Qty	No.	Part name	Qty
90	COVER COMP FAN	1	93	BOLT FLANGE	5
91	Starting Assy.	1	94	Switch	1
92	BOLT FLANGE	4	VII	RECOIL STARTER COMP	1

A-11 REGULATING CONTROL SYSTEM




No.	Part name	Qty	No.	Part name	Qty
95	BOLT FLANGE	2	99	ROD GOVERNOR	1
96	CONTROL ASSY	1	100	ARM GOVERNOR	1
97	Fine spring	1	101	NUT	1
98	SPRING THROTTLE RETURN	1	102	BOLT	1

A-12 FLYWHEEL



No.	Part name	Qty	No.	Part name	Qty
103	FLYWHEEL COMP	1	105	PULLEY STARTER	1
104	FAN COOLING	1	106	NUT SPECIAL	1

A-13 IGNITION COIL



No.	Part name	Qty	No.	Part name	Qty
107	COIL ASSY IGNITION	1	109		2
108	cable clamp	1			