



A-1 CRANKCASE ASSY




No.	Part name	Qty	No.	Part name	Qty
1	WASHER DRAIN PLUG	1	7	shim,SHAFT GOVERNOR ARM	1
2	BOLT DRAIN PLUG	1	8	SHAFT GOVERNOR ARM	1
3	crankshaft seal	1	9	Clip,SHAFT GOVERNOR ARM	1
4	bearing	1	10	oil alert	1
5	BOLT FLANGE	2	11	Nut,oil-alert	1
6	cable clamp	1	12	crank-case	1

A-2 CYLINDER HEAD & CYLINDER HEAD COVER ASSY




No.	Part name	Qty	No.	Part name	Qty
13	cylinder head cover	1	18	spark plug	1
14	gasket,cylinder head cover	1	19	D10 dowel	2
15	BOLT FLANGE	4	20	cylinder gasket	1
16	Exhaust pipe Paper pad	1	21	cylinder head	1
17	BOLT FLANGE	4			

A-3 CRANKCASE COVER ASSY




No.	Part name	Qty	No.	Part name	Qty
22	Oil plug assembly	1	29	Speed regulating gear gasket	1
23	D8 dowel	2	30	Speed regulating gear shaft	1
24	Hexagonal flange bolt	6	31	GEAR GOVERNOR	1
25	crank-case cover	1	32	Speed regulating gear gasket	1
26	Oil Ruler Assembly	1	33	bearing	1
27	crankshaft seal	1	34	Crankcase gasket	1
28	Speed adjusting cap	1	I	Speed regulating gear components	1

A-4 CRANKSHAFT, PISTON, CONNECTING & BALANCING SHAFT




No.	Part name	Qty	No.	Part name	Qty
35	crankshaft	1	42	piston ring A	1
36	connecting rod bolt	1	43	piston ring B	1
37	connecting rod cover	1	44	Oil ring scraper ring	2
38	connecting rod	1	45	Oil ring lining ring	1
39	piston pin	1	II	connecting rod Assy.	1
40	Piston pin Retaining ring	2	III	Piston Ring	1
41	piston	1			

A-5 Combination of camshaft & Valve rocker




No.	Part name	Qty	No.	Part name	Qty
46	LEFTER VALVE	2	55	Valve top cap	1
47	LEFTER VALVE	2	56	Inlet valve spring seat	1
48	PLATE ASSY	1	57	Inlet valve spring seat	1
49	Stud bolt,rocker arm	2	58	Oil shield	1
50	ARM VALVE ROCKER	2	59	VALVE IN	1
51	Rocker arm adjusting nut	2	60	VALVE EX	1
52	Rocker Hexagon Head Nut	2	61	camshaft	1
53	Exhaust valve spring	1	62	Camshaft gasket	1
54	Exhaust valve spring seat	1	IV	rocker arm Assy	1

A-6 CARBURETOR ASSY




No.	Part name	Qty	No.	Part name	Qty
63	PACKING CABURETOR	1	65	INSULATOR CARBURETOR	1
64	CARBURETOR	1	66	SPACER COMP AIR CLEANER	1

A-7 FUEL TANK ASSY




No.	Part name	Qty	No.	Part name	Qty
67	cable clamp	2	71	NUT	1
68	TUBE FUEL	1	72	FUEL tank	1
69	fuel tank cap	1	73	Hexagonal flange bolt	1
70	FILTER FUEL	1	V	FUEL tank	1

A-8 AIR CLEANER ASSY




No.	Part name	Qty	No.	Part name	Qty
74	COVER AIR CLEANER	1	80	NUT	2
75	ELBOW COMP AIR CLEANER	1	81	TUBE BREATHER	1
76	NUT	1	82	NOSE SILENCER	1
77	gasket	1	83	filter element	1
78	gasket	1	VI	air-filter	1
79	air-filter	1			

A-9 MUFFLER




No.	Part name	Qty	No.	Part name	Qty
84	MUFFLER ASSY	1	86	shock pad	2
85	Exhaust pipe Paper pad	1	87	NUT	2

A-10 RECOIL STARTER




No.	Part name	Qty	No.	Part name	Qty
88	Starting motor	1	93	BOLT FLANGE	4
89	Location Pin	2	94	BOLT FLANGE	3
90	Charging coil	1	95	RECOIL STARTER COMP	1
91	BOLT FLANGE	2	96	BOLT FLANGE	2
92	COVER COMP FAN	1	VII	RECOIL STARTER COMP	1

A-11 REGULATING CONTROL SYSTEM




No.	Part name	Qty	No.	Part name	Qty
97	BOLT FLANGE	2	101	ROD GOVERNOR	1
98	CONTROL ASSY	1	102	BOLT	1
99	SPRING THROTTLE RETURN	1	103	NUT	1
100	Fine spring	1	104	ARM GOVERNOR	1

A-12 FLYWHEEL




No.	Part name	Qty	No.	Part name	Qty
105	FLYWHEEL COMP	1	107	PULLEY STARTER	1
106	FAN COOLING	1	108	NUT SPECIAL	1

A-13 IGNITION COIL




No.	Part name	Qty	No.	Part name	Qty
109	Bolt	1	110	COIL ASSY IGNITION	1

A-14



No.	Part name	Qty	No.	Part name	Qty
111	Connecting wire	1	113	Connecting wire	1
112	Control box	1			

A-14



No.	Part name	Qty	No.	Part name	Qty
114	Diversion component	1	117	Diversion component	1
115	BOLT FLANGE	1	118	Pressboard	1
116	BOLT FLANGE	2			