



NO.	Part name	quantity
1	BOLT M6*12	8
2	CYLINDER CRANIUM	1
3	INLET VALVE SPRING SEAT	2
4	VALVE SPRINGS	2
5	LIMIT PLATE ASSEMBLY	1
6	VALVE OIL SEAL	2
7	BOLT M8*45	4
8	ROCKER ARM FASTENING BOLT ASSEMBLY	2
9	ROCKER ARM	2
10	THE SPARK PLUG	1
11	NUT M6	2
12	MUFFLER HOUSING	1
13	MUFFLER	1
14	PACKING,EXHAUST	1
15	STUD M6*95	2
16	CYLINDER HEAD	1
17	STUD M6*92	2
18	INTAKE GASKET	1
19	CARBURETOR CONNECTION BLOCK	1
20	CARBURETOR GASKET	1
21	CARBURETOR ASSEMBLY	1
22	AIR FILTER GASKET	1
23	AIR FILTER ELEMENT	1
24	NUT M6	5
25	TUBE	1
26	VERNIER C SPRING	1
27	THE THROTTLE LEVER	1
28	THE VALVE PUSH ROD	2
29	THE VALVE LIFTER	2
30	EXHAUST PIPE	1
31	INLET VALVE	1
32	THE EXHAUST VALVE	1
33	PISTON RING ASSEMBLY	1
34	THE PISTON	1
35	PISTON PIN RETAINER	2
36	THE PISTON PIN	1
37	CONNECTING ROD COMPONENT	1
38	GASKET,CYLINDER HEAD	1
39	CYLINDER HEAD LOCATING PIN	2
40	THE CRANKSHAFT BOX BODY	1
41	POSITIONING PIN OF CRANKCASE	2
42	THE CRANKSHAFT	1
43	CAMSHAFT ASSEMBLY	1
44	CRANKSHAFT TIMING DRIVING GEAR	1
45	FLAT WASHER	1
46	CENTRIFUGAL GOVERNOR GEAR ASSEMBLY	1
47	CRANKCASE COVER	1
48	BOLT M6*30	8
49	THE CRANKSHAFT OIL SEAL	1
50	BOLT M6*16	4
51	CONTROL ARM	1
52	SPEED REGULATING SPRING B	1
53	SPEED CONTROL CONTROLLER	1
54	SWINGING ROD	1
55	CHECK BACK CLIP	1
56	PENDULUM STEM SEAL	1
57	AIR DEFLECTOR	1
58	FUEL PIPE CLAMP Φ10	2
59	FUEL PIPE	1
60	FILTER	1
61	PLATE,BREATHER	1
62	BOLT M6*8	1
63	BACK TO THE OIL CHAMBER	1
64	BOLT M6*12	1
65	THE BRAKE COMPONENTS	1
66	FLAMEOUT WIRE	1
67	OIL GAUGE ASSEMBLY	1
68	THE CRANKSHAFT OIL SEAL	1
69	EXTENSION, OIL FILLER	1
70	WIND SHIELD,RH	1
71	OIL DRAIN BOLT WASHER	1
72	OIL DRAIN BOLT	1
73	IGNITER	1
74	BOLT STUD,IGNITION COIL	1
75	BOLT,BATTERY	2
76	IN THE HOOD	1
77	START THE TRAY ASSEMBLY	1
78	HOOD,FAN	1
79	START THE CUP	1
80	NUT M14*1.5	1
81	FAN,RECOIL STARTER	1
82	THE FLYWHEEL COMPONENTS	1
83	THE CAP	1
84	THE FUEL TANK	1
85	BOLT M4.2*16	1
86	FLAT WASHER	1
87	CRANKSHAFT FLAT KEY	1