



No.	Part name	Qty.
1	Battery terminal	1
2	Battery compartment parts	1
3	Locking knob	1
4	Chain plate cover	1
5	Chain plate cover rubber plug	1
6	14mm shaft circlip	1
7	Circlip	1
8	Sprocket retainer	1
9	Chain plate	1
10	Chian	1
11	Sprocket	1
12	Self-tapping screw 4.0*18.50	4
13	Self-tapping screw ST4.8*25	3
14	Self-tapping screw ST4.0*15	1
15	Self-tapping screw ST4.0*15	13
16	Chain adjusting parts	1
17	Screw ST4.0*12.0	1
18	Chain plate cover stop plate	1
19	Motor housing parts	1
20	Starter switch	1
21	Trigger	1
22	Trigger press spring	1
23	Self lock trigger press spring	1
24	Self lock trigger	1
25	PCB	1
26	Ening cover	1
27	Handle	1
28	Fuel tank parts	1
29	Safety damper	1
30	Safety damper pin	1
31	Self-tapping screw 3.5*10	1
32	Flat washer	1
33	Self-tapping screw M3x8	1
34	Safety damper spring plate	1
35	Stop switch	1
36	Bearing	1
37	Gear shaft parts	1
38	Bearing	1
39	Oil pump driving wheel	1
40	Circlip	1
41	Motor assembly gear assy	1
42	Spring	1
43	Oil inlet	1
44	Oil outlet	1
45	Self-tapping screw ST4.0*12	2
46	Oil pump parts	1
47	Guide bar sleeve	1